

The CarboyMop™

Instructions for use

The CarboyMop™ is a superior cleaning device for Brew-on-Premises (B.O.P.s) and home use. It will quickly and effectively remove stubborn deposits and (glass) carboy stains.



1. Add between 1 quart (1L) of your preferred beverage equipment cleaning solution or water to the carboy. For stubborn stains, chlorinated type cleaners work best.
2. Attach The CarboyMop™ onto an electric drill as per the diagram to the right. If cleaning a glass carboy, slide The CarboyCap™ adapter (included) over the top of the mop rod and attach to the drill. Ensure the embossed cap side faces the drill chuck. Securely tighten the chuck. Affix the adapter onto the opening of the glass carboy so the rod can easily move up & down. The CarboyCap™ stabilizes the mop and ensures dirt and water does not spin out of the carboy. If cleaning a plastic carboy, attach the properly sized bung (with a 3/8" hole) that fits your carboy neck size (not supplied).
3. Set the drill on a medium-fast, forward speed setting. Move the mop in an up & down motion to clean the inside walls and shoulders of the carboy. Gently maneuver the mop into the corners of the carboy.
4. Rinse the carboy with clean water after scrubbing. Repeat if necessary to remove stubborn stains.
5. After each use, clean the mophead with a mild dish detergent, and rinse well with clean water. Avoid the use of sulphites to clean stainless steel. To avoid surface oxidation, ensure agitator is dry before storing.
6. Replaceable mophead kits (microfiber strips/felt pads/plastic disc), and CarboyCaps™ (with hole & without hole) are also available from your dealer.

DO NOT operate the mop if the microfiber strips become loose, damaged or tangled. Remove the mophead microfiber felt pad, re-tighten the screw, and replace pad. Replaceable pads are also available at most grocery, hardware and dollar stores for a nominal cost.

DO NOT operate the mop outside of an enclosed container. The mop may also be used to clean the inside of most primary fermenters. If doing so, use a minimal amount of cleaning solution or water to avoid excessive spraying.

WARRANTY

This product is conditionally guaranteed against defective materials and workmanship for 1 year from the date of purchase. Guarantee void if product is damaged, altered, tampered with or otherwise misused.